

# **104 Flux Thinner**

#### **Product Description**

Kester Flux Thinners are used for reducing solids or replacing evaporated solvent, resulting in maximum efficiency of the flux in an open vessel application such as foam fluxing or dipping. To select a thinner, review the associated Technical Data Sheet. If you have any further questions please contact Kester Technical Support.

### Application

Flux thinners should be added if the Specific Gravity or the Titration test results indicate that the solvent needs to be increased. Test for flux balance should be performed every 4 hours of direct exposure to air. Please refer to the Technical Data Sheet for the proper test method and ranges.





#### Storage, Handling and Shelf Life

Solvent based thinners are flammable. Store away from sources of ignition. Shelf life is 3 years from the date of manufacture when handled properly and held at 10 to 25 °C (50 to 77 °F).

#### Health and Safety

This product, during handling or use, may be hazardous to your health or the environment. Read the Safety Data Sheet and warning label before using this product. Safety Data Sheets are available at https://www.kester.com/downloads/sds.

## **Contact Information**

To confirm this document is the most recent version, please contact <u>Assembly@MacDermidAlpha.com</u>

North America 800 West Thorndale Avenue Itasca, IL USA 60143	Asia Pacific 8/F., Paul Y. Centre 51 Hung To Road Kwun Tong, Kowloon, Hong Kong	<b>Europe</b> Ganghofer Strasse 45 82216 Gernlinden, Germany
Phone: +1 800.2.KESTER	Phone: +852.3190.3100	Phone: +49 (0) 8142 4785 0

Also read carefully warning and safety information on the Safety Data Sheet. This data sheet contains technical information required for safe and economical operation of this product. READ IT THOROUGHLY PRIOR TO PRODUCT USE. Emergency safety directory assistance: US 1 202 464 2554, Europe + 44 1235 239 670, Asia + 65 3158 1074, Brazil 0800 707 7022 and 0800 172 020, Mexico 01800 002 1400 and (55) 5559 1588

DISCLAIMER: All statements, technical information and recommendations contained herein are based on tests we believe to be reliable, but the accuracy or completeness thereof is not guaranteed. No statement or recommendation shall constitute a representation unless set forth in an agreement signed by officers of seller and manufacturer. NO WARRANTY OF MERCHANTABILITY, WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLED WARRANTY IS MADE. The following warranty is made in lieu of such warranties and all other warranties, express, implied, or statutory. Products are warranted to be free from defects in material and workmanship at the time sold. The sole obligation of seller and manufacturer under this warranty shall be to replace any noncompliant product at the time sold. Under no circumstances shall manufacturer or seller be liable for any loss, damage or expense, direct, indirect, incidental or consequential, arising out of the inability to use the product. Notwithstanding the foregoing, if products are supplied in response to a customer request that specifies operating parameters beyond those stated above, or if products are used under conditions exceeding said parameters, the customer by acceptance or use thereof assumes all risk of product failure and of all direct, indirect, incidental and consequential damages that may result from use of the product sunder such conditions, and agrees to exonerate, indemnify, defend and hold harmless MacDermid, Incorporated and its affiliates thereform. No suggestion for product are supplied in a suphale beins any patient or other intellectual property rights, and seller and manufacturer assume no responsibility or liability for any such infringement.

© 2019 MacDermid, Inc. and its group of companies. All rights reserved. "(R)" and "TM" are registered trademarks of MacDermid, Inc. and its group of companies in the United States and/or other countries.

